



1

Extend both canopy poles to full height. (3 poles with models 9130, 9146, 7001, and 7801)



2

Tie overhand knot into free end of guy ropes.




3

Take one corner of canopy and pull out from tent.

4

Insert tip on top of canopy pole into grommet on corner of awning. With first pole it may be helpful to place pole at a slight inward angle with base toward the tent.



6

On opposite end of the guy rope slide wood peg up rope to create a loop.

5

Place knot over tip of the canopy pole.

7

Stake loop into the ground.

8

Repeat steps 3 through 7 on opposite end of the canopy (on model 9130 secure center pole last which will be slightly taller than the two other canopy poles).

9

Tighten guy ropes by adjusting peg up rope.



Limited Warranty

Kirkham's® Outdoor Products warrants all Springbar® tent purchases for ten years. If an item is found defective, it will promptly be repaired or replaced.

Manufactured by
Kirkham's Outdoor Products



3125 South State / Salt Lake City, Utah 84115
Toll Free 1-800-453-7756 / (801) 486-4161

SPRINGBAR® Tents and multiple use shelters are manufactured under one or more of the following patents: U.S. 3,128,781; 3,367,671; 3,699,986; D208,748; 2323,28; Canadian Pat. Nos. 718,689; 230/29443; 230/29,444; 799,223; 299,222; French Pat. No. 1,500,526; and German Pat. No. 1,557,390. Other U.S. and foreign patents pending. SPRINGBAR® LEISURE PORT® SUPR-LYT® Registered Trademarks of AAA TENT & AWNING COMPANY® U.S. Patent Nos. 3,874,395; 3,965,915.