


CABIN STYLE FRAME SETUP INSTRUCTIONS

- STEP 1:** Lay out all the parts on the ground in the approximate place they should go.
- STEP 2:** Construct the top half of the frame according to the picture below. (Top half is everything but legs)
- STEP 3:** Place tent over the constructed half of the frame, making sure the door will open toward the direction you wish.
- STEP 4:** Lift up one side of the frame and install that side's legs, then lift the opposite side of the frame and install that side's legs.
- STEP 5:** Pull down the walls of the tent to the ground.
- STEP 6:** Secure guide ropes and tent to the ground with tent pegs.

Gold Fittings = Top Ridge
Silver Fittings = Side Eaves



SIDE POLE SIZES
8 x 10 x 12 }
10 x 12 x 5 } 3 Ribs
12 x 14 x 5 }
14 x 16 x 5 }
16 x 20 x 5 } 4 Ribs